

Battery Case for iPhone 4/4S Specification / User Manual



MOTA® is a trademark of UNorth® LLC.
Copyright © 2013 by UNorth, LLC. All Rights Reserved.
www.MOTA.com


Product Specifications:

ITEMS	SPECIFICATION	REMARK
Model	AP4-15	
Input Voltage	5.0V/1.0A(Max)	Charge
Output Voltage	5.0±0.25V/1A	
Nominal Capacity	1450mAh	
Adaptable for	iPhone 4/4S	
Cell Type	Li-polymer 1800mAh	
Standby Time	UP to 300h	
Talk Time	UP to 7h	
Internet Surfing Time	UP to 6h	
Audio Play Time	UP to 40h	
Video Play Time	UP to 10h	
Dimensions	15mm (T)x 62mm(W) x 127mm(L)	
Weight	55g	
Communicate	Synching with iTunes	


Features:

- Matching iPhone 4 / 4S design. Thin and Stylish.
- Capacity: 1450mAh (Li-Po) built in battery. Nearly doubles the life of your iPhone.
- Open slots for all iPhone 4/4S features. Use your phone without removing the case.
- Strong and Durable Material protect your iPhone from scratches and drops.
- Protective IC Circuit efficiently protects your iPhone against short circuits, over-charging, and malfunction.
- Changeable frames allow you to change the look of your case.

Illustration:



Installation



Installing:

- Slide your iPhone into the back cover of your MOTA battery case, then install the frame from top to bottom.

Uninstalling:

- Gently pull the bottom of the frame up by your fingernails. Slide the iPhone out.

Notes:

When your MOTA battery case's energy is fully drained, iPhone will show a non-charging battery icon.

The battery case includes a USB cable. Use the provided USB cable to charge your battery case.

Charging your Battery Case and iPhone 4/4S:

- Connect your battery case (iPhone already installed) to the USB power cable
- Connect the USB power cable to any USB power source such as computer to begin charging.
- Charge until the LED indicators read full.

Charging your iPhone with Battery Case:

- Press ON/OFF button (hold for 3 seconds) to charge your iPhone.
- Turning the battery case off when iPhone is fully charged will significantly save the charging capacity. Press ON/OFF (hold for 3 seconds) to power off the battery case.

LED Indicators:

MODE	CHARGING			
	LED1	LED2	LED3	LED4
Power<25%	BLINKING	OFF	OFF	OFF
25%<Power<50%	ON	BLINKING	OFF	OFF
50%<Power<75%	ON	ON	BLINKING	OFF
75%<Power	ON	ON	ON	BLINKING
FULL	ON	ON	ON	ON
MODE	DISCHARGING			
	LED1	LED2	LED3	LED4
75%<Power<100%	ON	ON	ON	ON
50%<Power<75%	ON	ON	ON	OFF
25%<Power<50%	ON	ON	OFF	OFF
Power<25%	ON	OFF	OFF	OFF
Empty	OFF	OFF	OFF	OFF

Package Contents:

- Battery Case
- USB power cable
- User Manual

Warning:

To maximize the life of your iPhone battery case, please fully charge the battery case before first use.

Be cautious of excessive drops, abrasions, or other impacts to the battery case. Immediately stop using if any abnormal indications appear.

Do not expose the battery case to wet or damp conditions.

Do not use near heat emitting appliances. Using USB cables than the one provided may result in compatibility issues.

Do not attempt to replace any spare parts of the pack.

It is normal for the battery case to get slightly warm when charging.

To dispose, take the battery case to your local battery recycling center.

iPhone® is a registered trademark of Apple® Inc.
Mota® is not affiliated to Apple® Inc.

MOTA® is a trademark of UNorth® LLC.
Copyright © 2013 by UNorth, LLC. All Rights Reserved.
www.MOTA.com