



MyWarmPet®

microwave safe heat pad

User Manual

This document contains important use and safety information. Please read the following information carefully before use. Please retain these instructions.

Get Ready!

Domestic Microwave ovens with no more than 1,500 watts of power can be used to warm the PICO® MyWarmPet® Heat Pad.

Please turn off any extra functions on your microwave such as grilling, browning, convections (if available on your microwave).

Please ensure the microwave is clean. Any residue from food or drinks can result in accelerated heating of the pad which could damage it.

Please place only one PICO® MyWarmPet Microwave Safe Heat Pad in the microwave at a time.

How to Heat

Remove your MyWarmPet Heat Pad from its cover and place it in your microwave's turntable, select full power (no more than 1,500) and select the appropriate time using this chart.

MICROWAVE POWER	TIME
600 – 650 watts	8 minutes
700 – 750 watts	7 minutes
800 – 850 watts	6 minutes
900 – 1,000 watts	5 minutes
1,100 – 1,200 watts	4 minutes
1,300 – 1,500 watts	2 ½ minutes

If your microwave does not have a turntable, please turn the Heating Pad manually half-way through the recommended time shown above.

After microwave time cycle is finished, please leave your MyWarmPet® Heat Pad in the microwave for one minute before removal to stabilize the temperature. Ensure to visually check the unit for any signs of accidental over-heating before removal (see Safety Warning Section below). Replace the cover.

CAUTION

MyWarmPet® Heat Pad will be hot at surface temperature of approximately 65 C / 149 F when heated according to the table above. If cover is removed, please use a cloth or over glove to handle it. If you prefer to use your MyWarmPet® Heat Pad without its cover, please place it under your pet's bedding and ensure pet cannot have contact with its surface to prevent burns.

HEAT CYCLE

In the first 3 hours of use, your MyWarmPet® Heat Pad will gradually reduce its heat to reach approximately 50 C / 122 F. It will then remain at this temperature for about 5 hours before it begins to cool down. Heat cycle will vary depending on the environment it is being used in. Please do not re-heat the MyWarmPet® Heat Pad until it has fully cooled down.

CLEANING

Use a damp cloth or spray your MyWarmPet® Heat Pad lightly with disinfectants and wipe it dry. Abrasive substances or scourers should not be used.

FOR VETERINARIANS

MyWarmPet® Heat Pad should never come into direct contact with an animal. At all times, heat pad should be covered with a cover, cloth, or suitable bedding to protect the animal from burn.

The use of this product is not recommended with animals that are anesthetized or unconscious as they cannot react to thermal discomfort.

Recovering animals which use this product should be monitored for their ability to move away from the unit should any discomfort arise. Never reheat MyWarmPet® until it has fully cooled down.

WARNING

Do not exceed the recommended heating times as overheating will damage your MyWarmPet® Heat Pad and may result in injury or burn.

Do not allow animals to bite or chew the unit.

Contents inside the MyWarmPet® Heat Pad will always react in a predictable way to heat. If used correct, unit will never distort or leak prematurely. If distortion or leak occurs, it has been overheated.

MyWarmPet® Heat Pad contains solid, non-toxic formula. During heating, about 10% of its content will become liquid and rest will remain solid. Overheating beyond 300% of the recommended time will result the content to melt and possibly leak.

Overheating will not result in an “explosion” – it will simply leak. If the unit seems damaged, deformed, or leakage is apparent, overheating has occurred and it will be dangerously hot. Do not open the microwave door until unit has cooled down – you should not attempt to touch, remove, or clean the leakage until unit has fully cooled down. When cool, any leakage of content can be removed from hard surfaces with hot water or scraped off with a suitable non-scratch object.

Do not allow children to heat up the MyWarmPet® Heat Pad unless properly supervised. Do not heat in a conventional oven or by any other method than described above. PICO® Pet, its agents, and distributors are not liable for any incidental or consequential damage arising from the use of this product. It is recommended that you replace the unit after 3 years.

For product support, please visit

www.picopet.com/support/

PICO® and MyWarmPet® are trademarks of UNORTH® LLC.
Copyright © 2013 by UNorth, LLC. All Rights Reserved.